

MIDI-Controller/Program Change for the C 951 Arpeggiator/C 951A Arpeggio Router

Arpeggiator-Menu with Program Change-Orders at the C 951A Router

PC	0	Send Data To ARP 1
PC	1	Send Data To ARP 2
PC	2	Send Data To ARP 3
PC	3	Send Data To ARP 4
PC	4	Send Data To All ARP

Controller for the Arpeggiators (n = chosen Nr. of the Arpeggiator(s) (s. PC-Orders))

Pitchbend		Transpose
CC	1	Stretch Factor ARP n (0 - 127)
CC	112	Low Note ARP n (0 - 127)
CC	113	High Note ARP n (0 - 127)
CC	117	Clock Divider ARP n 1/1 => Value 0 (- 31)
CC	117	Clock Divider ARP n 1/2 => Value 32 (- 63)
CC	117	Clock Divider ARP n 1/4 => Value 64 (- 95)
CC	117	Clock Divider ARP n 1/8 => Value 96 (- 127)
CC	120	Mute ARP n On => Value 127
CC	120	Mute ARP n Off => Value 0
CC	121	Reset ARP n*

***Reset ARP n**

- Clear Storage
- Gate Low
- Cycle => 1
- Mute => Off
- Clock Source => Internal Oscillator
- Clock Divider => 1/1
- Transpose 0
- Low Note => 36
- High Note => 108